

# Removing the top of an Ecolet

1. Unplug the toilet. Disconnect the ventilation pipe.



2. Remove the top by removing the nut holding the upper switch and the nut holding the compost cover.



3. Remove the thermostat dial.



4. Push the seat switch inside the plastic.



5. Lift off the top.



Clivus Multrum Australia Ph: 1300 13 81 82